





NO	Code	Name of Spare Parts	
1	30021200061	Pan Head Tapping Screw ST4.2x35	
2	30023300029	Gear Housing	
3	30010200009	Rubber Pin (4x6.8)	
4	30020600036	Spiral Bevel Gear Shaft	
5	30021500045	Pin	
6	30021400020	Ball Bearing 609SS (NMB)	
7	30120500084	Driven Gear	
8	30021600025	Circlip for Shaft 9	
9	30021400001	Ball Bearing 606ZZ	
10	30023400040	Gear Housing Cover	
11	30021400014	Ball Bearing 608ZZ (NSK)	
12		Armature Assembly	
13	30021200039	Pan Head Tapping Screw ST4.2x60	
14	30016300011	Insulation Washer	
15	30021400031	Ball Bearing 627ZZ (LFB)	
16		Stator Assembly	
17	30215400022	Motor Housing	
18		Nameplate	
19	30021600013	Circlip for Shaft 12	
20	30020600037	Large-arc Bevel Gear	
21	30021700016	Flat Key A (4x4x6)	
22	30271200015	Drill Chuck Assembly (with Bearing)	
23	30023000073	Bearing Holder	
24		Rear Cover	
25		Reversing Knob	

NO	Code	Name of Spare Parts	
26	30021200020	Pan Head Tapping Screw ST4.2x25	
27	30030800005	Brush Holder Cap / Pair	
28	30030600044	Carbon Brush / Pair	
29	30030700023	Brush Holder / Pair	
30		Reversing Level	
31	30030100049	Steering device	
32	30030900001	Speed Controller	
33	30030400006	Capacitor0.22 μ F	
34		Trigger	
35	30021200005	Pan Head Tapping Screw ST4.2x15	
36		Spring	
37	30116300007	Strain Relief	
38	30010100011	Cord Guard	
39		Adjusting Screw	
40	30021500046	Trigger pin	
41	30021600040	Split Washer 3	
42	30030300431	Cord 2x0.75x2.7	
43	30021600093	Washer (14x22x0.6)	
861	30071300010	Chuck Wrench (13mm)	
862	30015800022	Auxiliary Handle	
Set 1	30205000001	Rear Cover Assembly (C/W No: 24,25,30)	
Set 2	30024000098	Trigger Assembly (C/W No : 34,36,39)	
Set 3	30005100001	Spiral Bevel Gear Set (C/W No : 4,20)	
Set 4	30005090183	Drill Chuck Assembly (with Bearing and Chuck Wrench) (C/W No: 22,861)	