






NO	Code	Name of Spare Parts	
1	30010500001	Bearing Cover (19×21.2×8.6)	
2	30021400004	Ball Bearing 607ZZ (NMB)	
3	30016300014	Insulation Washer	
4		Armature Assembly	
5	30016000002	Guide Plate	
6	30010400002	Oil Seal (22×25.2×4)	
8	30021400011	Ball Bearing 608DD (NSK)	
9	30024000012	Circlip for Hole	
10		Driving Spiral Bevel Gear	
11	30021300018	Nut M7	
12		Lock Nut	
13		Autolocking Spring	
14	30021200020	Pan Head Tapping Screw ST4.2×25	
15	30023300027	Gear Housing	
16		Lock Pin	
17	30021400040	Ball Bearing 688ZZ (LFB)	
18		Driven Spiral Bevel Gear (L)	
19	30021400087	Ball Bearing 6201DDW (NSK)	
20	30023400029	Bearing Box	
21	30021100088	Pan Head Tapping Lock Screw M4×14	
22	30024000010	Dustproof Cover	
23	30120100052	Drive Spindle	
24	30029800006	Blade	
25	30021100004	Hex Socket Countersunk Head Screw M4×12	
26	30021600163	Washer (39×54×0.5)	
27	30029900020	Adjusting Ring	

NO	Code	Name of Spare Parts	
28	30015800031	Auxiliary Handle	
29	30021100005	Hex Socket Head Screw M6×8	
30	30029900043	Guide Holder	
31	30021100003	Hex Socket Head Screw M6×20	
32	30016000008	Baffle Plate	
33		Stator Assembly	
34	30016300004	Strain Relief	
35	30021200021	Pan Head Tapping Screw ST4×12	
37	30030100057	Switch	
38	30015500005	Rear Cover	
39	30030300432	Cord 2x0.75x2.7	
40	30010100007	Cord Guard	
41	30021200022	Pan Head Tapping Screw ST4.2×19	
42	30030400017	Terminal Block	
43	30030600042	Carbon Brush / Pair	
44	30021100227	Pan Head Tapping Screw ST2.9×9	
45	30030700026	Carbon Brush Holder / Pair	
46	30024500006	Coil Spring	
47	30215400006	Motor Housing	
48		Nameplate	
49	30021600217	Circlip for Hole 32	
861	30025100032	Hex Wrench 2.5	
862	30025100028	Hex Wrenc (3mm)	
863	30025100018	Hex Wrench (5mm)	
Set 1	30005090014	Locking Assembly (C/W No : 12,13,16)	
Set 2	30005090081	Gear Set (C/W No : 10,18)	