





NO	Code	Name of Spare Parts	
1	30223600001	Motor Housing	
2	30030700035	Carbon Brush Holder / Pair	
3		Stator Assembly	
5	30021100138	Pan Head Screw M5x55 (with Spring Washer)	
8	30010000014	Insulation Washer	
9		Armature Assembly	
11	30121600086	Lower Washer	
12	30023400011	Gear Housing Cover	
13	30021600088	Dust Seal	
15A	30021400164	Needle Bearing M661	
15	30021400163	Needle Bearing Y66	
	30021400054	Ball Bearing 6001ZZ (LFB)	
16	30024000242	Side Cover	
17	30023300040	Gear Housing	
22	30050900024	Oil Felt	
23	30021200009	Pan Head Tapping Screw ST4x22	
23A	30021100090	Pan Head Screw M4x10 (with Spring Washer)	
26	30021400109	Ball Bearing 6204VV (LFB)	
27	30024000040	Bearing Retainer	
28	30020500004	First-class Gear	
30	30021100095	Hex Socket Head Screw M5x12	
32	30024000235	Oil Gauge	
33	30020700002	Middle Shaft	
34	30020600019	Bevel Gear	
35	30010000013	Clutch Plate	
36	30020500059	Clutch Gear	
37	30021600090	Washer	
38	30021600092	Spring Washer	
39	30021300023	Lock Nut	
40	30021600089	Lower Washer	
41	30021600091	Washer	
42	30021400034	Ball Bearing 629VV(NSK)	
43	30021100148	Hex Socket Head Screw M6x45	
45	30029900100	Connecting Rod	
46	30021400165	Needle Bearing AJ500 1203	
47	30021500018	Piston Pin	
48	30029900053	Piston	
49	30010000080	X-Ring (24.5x2.5)	
50	30023000017	Striker	
51	30024000037	Oil Seal	
52	30023700012	Cylinder	
53	30021400167	Slide Bearing	
54	30020400003	Drive Shaft	
55	30121400212	Ball Bearing 6001ZZ(NSK)	
56	30020500006	Gear	
57	30021700001	Woodruff Key (3x3.7x10)	
58	30021600218	Spring Washer 8	
59	30021300024	Lock Nut (S)	
60	30021600085	Cylinder Washer	
61	30010000093	Damping Washer B	
62	30021600185	Split Washer	
63	30029900054	Distance Washer	
63A	30029900004	Cylinder Sleeve	
64	30010000094	Damping Washer A	
65	30021600084	Washer	

NO	Code	Name of Spare Parts	
66	30020500005	Hex-hole Gear	
67	30029900063	Front Cover	
68	30010000011	Dust Cap	
69	30021100108	Hex Socket Head Screw M6x20	
71	30029900064	Retainer	
73	30010000010	Rubber Sleeve	
74	30021600082	Washer 1	
75	30024500015	Compression Spring (13.6x1.4x39.5)	
76	30029900101	Spindle Sleeve	
77	30021500043	Needle Roller	
78	30029900055	Stopper Ring	
81	30021600083	Washer 2	
84	30021100455	Hex. Socket Head. Screw M5x12	
86	30021100097	Pan Head Screw M5x10 (with Spring Washer)	
91	30030300442	Cord (3x1.0x3.5)	
92	30010100010	Cord Guard	
94	30021100125	Pan Head Screw M4x8(with Spring Washer)	
96		Left-Half Handle	
97	30030600020	Carbon Brush / Pair	
98	30030800015	Brush Holder Cap / Pair	
99	30024000042	Tail Cover	
101	30115800004	Auxiliary Handle	
105	30021100096	Hex Socket Head Screw M5x8 With Flat Point	
107		Nameplate	
128	30021100108	Hex Socket Head Screw M6x20	
129	30021200048	Pan Head Tapping Screw ST4.2x17	
130	30021100141	Hex Socket Head Screw M6x25	
131	30021600086	Washer	
132	30021600221	Circlip for Shaft 15	
501	30030400007	Capacitor 0.33μF	
502	30010000034	Oil Seal	
503	30024000233	Screw Cover	
10A	30021400042	Ball Bearing 6000VV(NSK)	
14A	30021400098	Ball Bearing 6202ZZ(NSK)	
25B	30020300004	Crank Shaft	
29A	30021700018	Flat Key (4x4x14)	
72A	30029900103	Connecting Rod A (Short)	
79C	30029900102	Connecting Rod B (Long)	
82A	30024000039	Oil Seal	
83A	30024000038	Cap	
88A		Right-half Handle	
89D	30030100087	Trigger Switch	
90C	30010000012	Switch Cover	
93A	30016300002	Strain Relief	
52A	30029900104	Cylinder	
861	30240900027	Plastic Box	
862	30025100024	Wrench	
863	30025100018	Hex Wrench (5mm)	
864	30019900238	Oiler Assembly	
Set 1	30005000033	Front Cover Assembly (C/W No : 67,68,71,72A,79C,73,73,74,74,75,75,76,76,77,77,78,78,81,81)	
Set 2	30005000008	Connecting Rod Assembly (C/W No : 72A,79C,73,73,74,74,75,75,76,76,77,77,78,78,81,81)	
Set 3	30019900105	Damping Washer Assembly (C/W No : 60,61,63,64,65)	
Set 4	30005000011	Handle Set (C/W No : 88A,96)	
Set 5	30023700011	Cylinder Assembly (C/W No : 52,52A,63A)	