






NO	Code	Name of Spare Parts	
1	30271200001	Drill Chuck(6mm)	
2	30021600202	Washer	
3	30021200008	Pan Head Tapping Screw ST4.2×16 (with Flat Washer)	
4	30023700014	Barrel	
5	30021400045	Ball Bearing 6000ZZCG7E/NSS (NSK)	
6	30024000170	Bearing Retainer	
7	30021100125	Pan Head Screw M4×8 (with Spring Washer)	
8		Armature Ass'y	
9	30116300025	Insulation Washer	
10	30021400004	Ball Bearing 607ZZ (NMB)	
11	30010500001	Bearing Cover (19×21.2×8.6)	
12	30016000010	Baffle Plate	
13	30021200039	Pan Head Tapping Screw ST4.2×60	
14		Stator Assembly	
15	30215400029	Motor Housing	
16		Nameplate	
17	30030600046	Carbon Brush / Pair	
18	30005090095	Carbon Brush Holder / Pair	
19	30024500063	Coil Spring	
20	30015500006	Rear Cover	
21	30021200042	Pan Head Tapping Screw ST4×15	
22	30016400001	Switch Knob	
23	30030100054	Switch	
24	30016400013	Switch Lever	
25	30024500064	Compression Spring (3.6×0.4×18)	
26	30016300004	Strain Relief	
27	30021200021	Pan Head Tapping Screw ST4×12	
28	30030400011	Capacitor 0.33μF	
29	30010100007	Cord Guard	
30	30030300431	Cord (2x0.75x2.7)	
861	30029900009	Chuck Wrench	