





NO	Code	Name of Spare Parts	
1	30021200008	Pan Head Tapping Screw ST4x16	
2	30215700033	Handle Cover	
3	30030400055	Capacitor0.22µF	
4	30021200048	Pan Head Tapping Screw ST4.2x17	
5	30016300006	Strain Relief	
6		Cord 2x1.5x2.7	
7	30110100008	Cord Guard	
8	30030100106	Trigger Switch	
9	30223600129	Motor Housing	
10	30023000084	V-Pulley (S)	
11	30119900018	Belt Cover	
12	30021100088	Pan Head Tapping Lock Screw M4x14	
13	30030800008	Brush Holder Cap / Pair	
14	30030600012	Carbon Brush / Pair	
15	30030700011	Carbon Brush Holder / Pair	
16	30021200018	Pan Head Tapping Screw ST4.8x44	
17	30215700032	Handle Cover	
18	30019900275	Dust-collecting Casing	
19	30010300071	O Ring (28x2)	
20	30023000086	Side Cover	
21	30021200082	Pan Head Tapping Screw ST4.2x45	
22		Label	
23	30021200084	Pan Head Tapping Screw M4x40	
24	30024000253	Guide Plate	
25	30021100124	Pan Head Screw M5x10	
26	30023500003	Fan	
27	30023400048	Gear Housing Cover	
28	30021400042	Ball Bearing 6000VV (NSK)	
29		Armature Assembly	
30	30016000047	Baffle Plate	
31	30016300032	Insulation Washer	
32	30021400042	Ball Bearing 6000VV (NSK)	
33		Stator Assembly	
33A	30030500054	Stator Wire 365	
33B	30030500053	Stator Wire 70	
34	30010000104	Belt 354-3M9	
35	30021100234	Hex Nut M10	
36	30023000080	V-Pulley (L)	

NO	Code	Name of Spare Parts	
37	30024000257	Bearing Retainer	
38	30020500128	Gear	
39	30020100081	Drive Spindle	
40	30029900170	Spindle Sleeve	
41	30029900169	Base	
42	30024000267	Sandpaper Baffle	
43	30021400051	Ball Bearing 6001VV (NSK)	
44	30029900183	Driving Wheel	
45	30021100217	Hex Nut M12 (left)	
46	30024300029	Safety Guard	
47	30021100088	Pan Head Tapping Lock Screw M4x14	
48	30024500078	Compression Spring	
49	30020000029	Extension Spring	
50	30024000268	Grinding Carriage Assembly	
51	30021600013	Circlip for Shaft 12	
52	30019900279	Stop Screw	
53	30020700029	Spindle	
54	30024000277	Driven Wheel Cover	
55	30021600126	Dustproof Seal (12.1x21.5x1.5)	
56	30029900179	Driven Wheel	
57	30021100100	Pan Head Screw M4x12 (with Spring Washers)	
58	30024000260	Washer	
59	30024000269	Steel Plate	
60	30010000095	Rubber Pad	
61	30021400133	Needle Bearing HK0810 (INA)	
62	30020500127	Gear Shaft	
63	30021400081	Ball Bearing 6200VV (LFB)	
64		Nameplate	
65	30024500079	Adjusting Spring	
66	30024000259	Washer	
67	30019900140	Screw II	
ACC 1	30009800009	Dust Bag (Including dust bag assembly and dust bag holder)	
ACC 2	30071300006	Abrasive Belt R/R H 100x610mm A P80	
ACC 3	30071300012	Abrasive Belt R/R H 100x610mm A P60	
ACC 4	30071300013	Abrasive Belt R/R H 100x610mm A P100	
ACC 5	30071300014	Abrasive Belt R/R H 100x610mm A P120	
ACC 6	<b>30071300020</b>	Abrasive Belt R/R H 100x610mm A P 180	
ACC 7	30071300015	Abrasive Belt R/R H 100x610mm A P240	
ACC 8	30071300016	Abrasive Belt R/R H 100x610mm A P320	